

Quick and easy assembly User's manual

Self-Contained Pro

Includes: 4 struts, 4 casters, 4 joints

- 1. Divide the 2 struts from each other by gently pulling them apart at the ends.
- 2. Divide the joints from the struts by pushing them gently and then divide the 2 smaller struts from the bigger ones.
- 3. Assemble the 4 struts in a square.
- 4. Place the joints in the holes and gently push them locking the 4 struts together.
- 5. Place the casters in the holes on each joint.

All parts click in each other by press fit, no tools required.





ENJOY dozop